

REMARK:

Warning alarm switch is at right bottom side, voice died with door closed, then spring out buzzer and make continuous warning. Operation guidelines. access controller initialization: after power off, connect bin 2 and bin 3 of s16 supply power, buzzer make continuous warning alarm, power light (red light), ok (green) light and mode (orange) light and mode (orange) light all flash.

Cut off power, then connect power supply, All lights, including POWER, OK and mode, flash, waiting for exchanging s16 switch Bin 2 Bin 3 disconnected, Bin 1 and Bin 2 connected.

Access controller initialization is completed, after a voice of buzzer, controller will be available for user.

REMARK: Initialization only modify system password to default password (default when ex-work), other data will not changed. Electrical lock assembling

When connect Bin 1 and Bin 2, open signal is outputted (power on and door open) ; When connect bin 2 and bin 3, close signal is outputted (power off and door closed); drive voltage for electrical lock is 12v.

How to set up access controller system program "#" key: function key, go into system edit mode push "#", then red, green and orange and orange lights all work. Input 5 system passwords and a voice of buzzer is made. "O" key: log on user card plus password push "O" key, orange light lights, red and green lights die. Input 4 digital user no. valid.

After reading user card, a buzzer invoice happened, then again input 6 digitals password, a long buzzer invoice happened, green lights died after flash, orange and red light lights and user logged on successfully. "1" key: modify system password push "1" orange light lights, red and green lights die. User inputs 5 digit number password (such as 23456), once input completed, buzzer makes a short voice, green light died after flash, red light and orange lights light, then modification of password is successful.

Caution: please user keep password well, when you go into system program mode again, need input the password, if forget it, please execute initialization process.

"2" key: log on user card, or password push "2" key, orange light lights, red and green lights die. Input 4 digital user no. green light lights, showing user no. valid, if buzzer makes 3 invoices, showing that the user no. already logged on; if buzzer make 4 long continuously voices. Showing memory is full, can't log on.

After reading user card, or inputting 6 digitals password, green light died after flash ; orange and red light light and user logged on successfully. If buzzer make 3 continuous voices, showing that the card or password already logged on, can't repeatedly log on. "3" key: delete solo user card or password, or card plus password. Push 3 key, orange light lights, red and deleted, a long buzzer is made "4" key: delete all user card or password or card plus password

Push "4", a long buzzer is made, green light die after flash ,orange and red light, showing all user data are deleted

"5"key: set up time of opening door. push "5", orange light lights, red and green lights died,

Input "2" digital number for open door time, buzzer make a long voice, green light, died after flash, orange and red lights light, the time of open door is set up successfully. "6"key:exit key.

Buzzer makes a long voice, green light die after flash, red light lights, orange light dies, access controller exits from system program mode and goes into normal work mode.

Description: during system program process, if type error or wrongly operation, controller will make warning alarm for incident with 3 long buzzers and return to normal use status. If 5 2-short -1-long buzzers are made, show system memory reads wrongly.

Once dccess controller edit is completed, goes into normal work status, red light lights, orange and green lights die.

Refer to below for guideline put user card near to access controller or continuously input 6 digitals user password, buzzer make a long voice, green light lights, red light dies and door opered ; within the time set-up open door, the status that light shows keep the same.

If buzzer makes 3 short voices, red light continuously flash 3 times, showing card or password is illegal and can't open door.

For user who selects card & password type (set-up for user log on), ask that after input card or password, then in put according password or card, showing valid with 1 long buzzer and door is opened; if invalid, exit and wait for re-input.

Caution: the access control meantime supports card password, card plus password and password plus card (card & password type). Card can't be read when door open; when user push button and input password Card can't be read.

Packing list:

RF-C access controller	1 set
User manuel	1 piece
Plastic insert for fixed and screw	1 bag

